

# ITH Teddy Aviator



.PES  
.DST  
.VP3  
.JEF  
.XXX  
.HUS  
.EXP

Digital  
files  
16x16  
20x30  
-----  
6x10"  
8x12"

WHAT IS NEEDED:

Foam 1 cm  
Padding 1 cm  
Felt or fabric of your choice



Put it in the frame tear-away stabilizer Embroider the position track  
Place the foam rectangle Embroider the next track - Cut out the shape  
Place the padding on top of the foam, secure with pins or tape Embroider the following seam - Cut out the excess padding



All subsequent steps are normal applique and embroidery where needed  
Be careful not to skip the penultimate step where the lining is to be placed  
on the reverse of the hoop  
Before proceeding, carefully observe the entire sequence of images



To speed up I wanted to embroider the banner in the same frame as the plane but I recommend doing it in a separate frame



For all the elements that make up the project, the procedure is always the same  
Double padding for the air and for the banner  
Only foam for all other items

