For these Key Fob Design, you will need the following:

2 pieces of vinyl, leather, or any material that can be embroidered on, but will not fray.

5x7in/130x180mm design: 2in x 8in/4cm x 19cm

Tear away stabilizer.

Snaps and snap tool.

Fabric/craft glue, tape or spray adhesive

Key chain hard ware

- 1. Hoop your stabilizer then run the first placement stitch directly onto your stabilizer
- 2. Place a piece of vinyl (or any type of fabric that does not fray) on your hoop covering the placement stitches. Be sure to cover at least 1/2 inch/1,25cm all the way around your design. You may want to tape the vinyl to the stabilizer on the sides so that the design/vinyl does not shift. If you do use tape, make sure that it will not interfear with the stitching.
- 3. At his point, stitch out the tackdown stitch (the placement and tack down stitches will not be a part of the finished project. They are used for placement and are also a guide for cutting/trimming the finished product.
- 4. Next, stitch out all parts of your design except for the last step/color.
- 5. Remove your hoop from the machine, but do not remove the piece from the hoop! Now place a piece of felt, fabric or vinyl on the back of the hoop, using the first placement stitches (#1) as a quide. Secure the piece with spray adhesive or tape. Place your hoop back on your machine.
- 6. Now using the color you want your final outline stitch to be, sew out the last remaining step.
- 7. Now remove your project from the hoop and carefully trim around your design. Depending on the size and motive of your key fob, pinking shears can also be used, giving your project an extra touch!
- 8. Now attatch the snaps or glue together. Attatch the key chain.